

AJAX

1926 AJAX Late, 6 cyl

Engine & headlight	108.45
Cowl lights/pr	12.00
Cowl wires.....	9.35
Spark plug & coil wires	20.65

ALLSTATE

1953-54 ALLSTATE

Cowl, engine & headlight (4 cyl).....	260.85
Overdrive harness (4 cyl)	67.65
Interior light switch (4 & 6 cyl)	35.20
Oil pressure sender (4 & 6 cyl)	14.40
Misc. wires (4 cyl).....	9.60

AUSTIN

1930-32 AMERICAN AUSTIN

Main lighting & engine	135.00
------------------------------	--------

AMERICAN LAFRANCE

1937 AMERICAN LaFRANCE FIRE TRUCK

Cowl & engine.....	219.30
Headlight harness	46.90
Headlight harness	62.50
Headlight wire.....	18.95
Siren button to siren	30.50
Pump panel light harness	38.25
Starter button to starter wire	13.25
Misc. wires	12.60

AUBURN

1929-30 AUBURN, Model 6-80, 6-85, 8-90, 120 & 125

Dash light wires	12.50
------------------------	-------

1931 AUBURN, Model 8-98 & 8-98A

Cowl & engine	122.00
Headlight (8-98).....	65.00
Headlight (8-98A).....	66.25
Headlight buckets/pr	25.00
Dash light wires.....	7.00
Body (8-98).....	51.75
Body w/ 1 taillight (8-98A)	52.50
Body w/ 2 taillights (8-98A)	69.75
Taillight buckets/each (8-98A)	10.50
Radio antenna harness.....	34.30

1932-33 AUBURN, Model 8-100, 8-101 & 8-105

Cowl, engine & headlight	150.60
Dash light wires.....	7.00
Headlight harness	50.05
Body w/ 1 taillight	40.95
Taillight buckets/each.....	9.60
Taillight cross-over.....	18.00

1932-33 AUBURN, Model 160, 161 & 165

Cowl & engine (161A)	193.35
Cowl & engine (165, 1250)(160)	183.55
Cowl, engine & headlight ("Boattail Speedster", V-12).....	194.45
Cowl & engine (Roadster)	183.60
Dash light wires.....	7.00
Headlight harness	121.00
Headlight feed wires (set of 4)	23.45
Horn harness/pr	43.45
Body w/ 2 taillights ("Boattail Speedster", V-12).	145.45
Negative battery to startix cable.....	41.75
Positive battery to ground cable.....	19.60
Startix to starter cable.....	18.35

1934 AUBURN, Model 8-50-Y

Cowl & engine w/ startix	211.00
Headlight w/ tilt headlights	108.70
Headlight buckets/pr	63.20
Body w/ 2 taillights.....	62.85
Misc. under dash wires.....	66.70
Taillight buckets/each.....	14.70
Negative battery to startix cable	47.75
Positive battery to ground strap.....	16.00
Starter ground strap.....	14.00
Starter to startix cable.....	15.60

1933-34 AUBURN, Model 12-165 (12 cyl)

Body	64.00
Taillight cross-over.....	45.00

1935-36 AUBURN, Model 851 & 852

Cowl & engine	187.95
Headlight harness	92.60
Headlight buckets/pr	34.00
Body harness	71.00
Taillight buckets/pr.....	21.10
Misc. under dash wires & clock harness	58.00
Horn harness	15.00
Spark plug wires.....	35.00
Starter to startix cable.....	15.60
Positive battery strap	16.00
Negative to startix cable.....	47.75
Frame to starter strap.....	14.00

1935-36 AUBURN (Right-hand drive)

Cowl, engine & headlight	190.40
Headlight cross-over	49.20
Headlight buckets/pr	34.00
Body	71.00
Taillight buckets/pr	21.10
Misc. wires & under dash harness	58.00
Horn harness	15.00
Spark plug wires	35.00
Starter to startix cable	15.60
Positive battery strap	16.00
Negative to startix cable	47.75
Frame to starter strap	14.00

BANTAM

1937-41 BANTAM, Series 60, 63 & 65

Cowl, engine & headlight	66.00
Headlight buckets/pr	40.80
Misc. dash & engine wires	33.60

CORD

1929-32 CORD I-29

Cowl & engine	273.90
Headlight harness	19.85
Headlight junction block to headlights kit.....	9.90
Body & taillight.....	95.70
Interior lights – Brougham.....	100.80
Misc. dash wires.....	8.80
Negative to starter switch cable	29.00
Positive to ground cable.....	17.85

1936-37 CORD 810 & 812

Cowl & engine w/ startix	287.00
Body – sedan	99.50
Body – phaeton	91.50
Headlight harness	67.85
Headlight buckets/pr (original w/o sockets)	33.25
Headlight buckets/pr (w/ sealed beams).....	35.50
Interlock & selector harness	85.05
Neutral switch valve selector	19.75
Generator to voltage regulator	23.75
Transmission ground strap.....	19.25
Steering column wires	26.80
Horn button wire.....	9.65
Taillight buckets/pr.....	22.60
Coil to distributor wire.....	8.95
Trunk light wire	17.50
Spark plug wires (Please specify if you would like them black or oak.).....	36.00
Starter to startix cable.....	15.30
Positive ground strap.....	18.75
Negative battery to battery	47.00

CROSLEY

1939-40 CROSLEY, Model A

Cowl, engine & main lighting.....	112.30
-----------------------------------	--------

1941 CROSLEY, Model CB-41

Cowl, engine & main lighting	112.30
------------------------------------	--------

1942 CROSLEY, Model CB-42

Cowl, engine & main lighting	112.30
------------------------------------	--------

1946-48 CROSLEY

Cowl, engine & main lighting	220.75
Generator to voltage regulator	14.25
Engine ground strap	16.90
Positive battery cable.....	23.50
Negative battery cable	22.20

1949-52 CROSLEY, Model CD

Cowl, engine & main lighting.....	297.40
Taillight buckets/pr.....	24.30
Headlight buckets/pr	31.45
Park & turn buckets/pr	21.50
License lamp plate wires.....	15.60
Turn signal switch harness.....	52.95
Engine ground strap.....	13.00
Positive battery cable.....	23.50
Negative battery cable	18.50

1949-52 CROSLEY, Model VC

Cowl, engine & main lighting	297.50
Taillight buckets/pr	24.30
Headlight buckets/pr	31.45
Park & turn buckets/pr	21.50
License plate wires.....	15.60
Turn signal switch harness.....	52.95
Engine ground strap	13.00
Positive battery cable	23.50
Negative battery cable.....	18.50

DIAMOND “T”

1947 DIAMOND “T” PICK-UP TRUCK

Cowl, engine & headlight	233.15
Cowl, engine & headlight w/ options.....	279.75
Body	81.25
Body w/ options	97.55
Flasher harness	26.70
Taillight cross-over.....	17.35

DUESENBERG

1926 DUESENBERG

Body w/ back-up lights & 1 taillight..... 117.35

1929-37 DUESENBERG, Model J

Note: Please specify long or short wheel base. Pilot ray or trippe lights.

Cowl..... 117.05
Headlight 85.80
Headlight (Pilot Ray or Trippe light)..... 94.60
Body (Short wheel base) 153.75
Body (Long wheel base)..... 157.50
Lubrication signal light harness 68.75
Positive battery – starter cable (Cadmium) 52.80
Positive battery – starter cable (Stainless) 57.20
Negative battery – ground strap 23.00
Starter – frame strap 12.65

ESSEX

1928-29 ESSEX CHALLENGER

Ammeter to generator & starter harness 36.95
Junction block harness 87.25
Main lighting..... 63.60
Misc. dash wires & coil harness..... 45.55

1931 ESSEX E-31, 6 cyl

Cowl to headlight switch harness..... 66.00
Body 69.75
Ammeter to generator relay & starter switch..... 29.00
Headlight harness/pr 43.45
Ignition switch to coil & distributor 26.85
Headlight bucket wires..... 4.65
Horn harness 21.20
Negative post to ground strap..... 12.85
Positive post to starter switch 28.25

FLINT

1924-26 FLINT E-55 & E-80

Left headlight & body kit..... cadmium 150.70
Left headlight & body kit..... stainless..... 203.60
Right headlight, engine & horn kit- cadmium 130.80
Right headlight, engine & horn kit- stainless..... 156.65

FRANKLIN

1925-26 FRANKLIN, Series 11-A

Spark plug wires..... 27.50
Battery cable set (Neg. & Pos.) 56.75

1930 FRANKLIN convertible coupe, Model 145

Headlight, horn & park cross-over (cadmium)... 117.00
Headlight, horn & park cross-over (stainless).... 125.55
Positive battery to starter switch..... 37.95
Starter switch to starter 20.35

1931 FRANKLIN, Series 15, Models 151, 152 & 153

Headlight harness 73.55
Body 67.40

GARDNER

1927-29 GARDNER

Cowl & engine 66.55
Headlight..... 60.00
Body w/ 1 taillight 55.05
Fuel tank wire..... 23.15

GRAHAM

1928-29 GRAHAM PAIGE, Model 619

Headlight & dash wires 183.05

1930 GRAHAM STANDARD SIX, Model 44

Cowl, engine & main lighting 181.90

1936 GRAHAM CAVALIER 90, 90A & SUPERCHARGER 110

Main lighting 205.75
Headlight 85.80

1937 GRAHAM SUPERCHARGER 116 & 120 W/ TYPE 948B GENERATOR

Main lighting..... 205.75
Headlight 85.80

1937 GRAHAM, Model 95

Cowl & engine 202.50
Body w/ 2 taillights..... 99.75
Headlight 81.80
Dual horns 43.10

1938-39 GRAHAM, STANDARD & SPECIAL Model 96 & SUPERCHARGER 97

Cowl, engine & headlight w/ dual horns 235.20
Clock & glove box 39.60
Dash light & switch harness 14.30
Generator to regulator..... 16.45

1940 GRAHAM, STANDARD & SPECIAL Model 108 & SUPERCHARGER 107

Cowl, engine & headlight w/ dual horns	235.20
Clock & glove box	39.60
Dash light & switch harness	14.30
Generator to regulator.....	16.45

1940-41 GRAHAM HOLLYWOOD

Cowl, engine & headlight	210.00
Body	53.60
Taillight cross-over.....	22.45
Taillight buckets/pr.....	20.25
License light & bucket wires	28.60
Headlight buckets/pr	61.45
Instrument light & dash wires.....	28.20
Horn harness & coil to distributor	17.40
Horn relay harness.....	15.60
Dome light harness.....	24.95

HAYNES

1916-17 HAYNES, Models 36R & 37

Cowl, engine & headlight	192.00
Body	104.50
Negative battery cable	49.50
Positive battery cable	45.75

HENRY J

1952 late HENRY "J"

Cowl, engine & headlight (4 & 6 cyl)	238.25
Overdrive (4 & 6 cyl).....	64.20
Interior light switch harness	34.40
Oil pressure sender	14.35
Misc. wires – gauges, coil to distributor, ignition Switch to heater switch	7.50
Park & turn buckets/pr	29.85

1953-54 HENRY "J"

Cowl, engine & headlight (4 cyl)	236.40
Overdrive (4 cyl).....	62.40
Interior light switch (4 & 6 cyl)	32.50
Oil pressure sender (4 & 6 cyl)	14.30
Misc. wires (4 cyl)	9.60

HUDSON

1928-29 HUDSON SUPER SIX

Ammeter to generator & starter harness.....	36.95
Junction block harness	87.25
Main lighting	63.60
Misc. dash wires & coil harness.....	45.55

1935 HUDSON BIG SIX, Model GH, 2dr Deluxe

Cowl, engine & body	385.00
Headlight	97.30
Headlight buckets/pr	74.40
Generator to voltage regulator	45.85
Taillight buckets/ea	13.50
Misc. wires	19.25

1937 HUDSON PANEL DELIVERY

Cowl, engine & body	209.00
Headlight	55.20
Headlight buckets/pr	41.25
Generator to voltage regulator	19.75

1941 HUDSON, 6 cyl.

Turn signal switch harness	31.45
Headlight connector harness.....	26.40
Voltage regulator to generator	16.90
Horn wires (twin horns)	14.60
Coil to distributor	3.60

1941 HUDSON Commodore Eight, Model 14 (Conv.)

Cowl, engine & headlight	325.75
Headlight connector harness	30.30
Headlight buckets/pr	64.25
Taillight buckets – right hand.....	45.50
Taillight buckets – left hand	39.40
Turn signal switch harness.....	38.70
Front turn signal wires/pr	38.35
Gas tank sender wire	12.35
Coil to distributor wire	7.00
License light harness	18.00
Generator harness	21.35
Overdrive harness	86.10
Body – conv.	84.35
Horn wires	18.05

1942 HUDSON Commodore Eight, Model 24

Cowl & engine	266.60
Headlight harness	37.75
Headlight buckets/pr	43.20
Overdrive harness	84.35
Body harness – conv.....	66.00
Generator harness	13.20
Taillight buckets/pr	67.65

1946-47 HUDSON Super 6, Model 51 & 171

Cowl & engine	223.05
Headlight harness	37.75
Headlight buckets/pr	43.20
Dimmer switch harness	34.55
Fog light wires	31.35
Park light buckets w/ turns.....	32.90

*continued on next page.

1946-47 HUDSON Super 6, Model 51 & 171

Misc. dash wires.....	26.55
Engine harness	87.10
Generator harness.....	13.20
Gas tank sender wire	14.50
Horn relay harness.....	30.05
License plate light harness	9.35
Distributor to coil wire.....	6.90
Body – conv.	66.00
Taillight buckets/pr.....	67.65
Hood ornament light wires.....	8.30
Conv. top wires	39.00
Overdrive	84.35
Heater wires	9.25
Spark plug wires.....	26.70
Solenoid to hydraulic pump	39.95
Positive battery cable	24.20
Negative battery cable	41.25

1946-47 HUDSON Commodore Eight, Model 54 & 174

Cowl & engine	266.60
Headlight harness	37.75
Headlight buckets/pr	43.20
Dimmer switch harness	34.55
Fog light wires	31.35
Park light buckets w/ turns.....	32.90
Misc. dash wires.....	26.55
Generator harness	13.20
Gas tank sender wire	14.50
Horn relay harness.....	30.05
License plate light harness	9.35
Distributor to coil wire.....	6.90
Body – conv.	66.00
Taillight buckets/pr.....	67.65
Hood ornament light wires.....	8.30
Convertible top harness.....	39.00
Overdrive	84.35
Heater wires	9.25
Spark plug wires.....	26.70
Solenoid to hydraulic pump	39.95
Positive battery cable.....	24.20
Negative battery cable.....	41.25

1948-49 HUDSON

Cowl & engine	202.00
Engine harness (6 cyl).....	72.45
Headlight harness	43.90
Headlight cross-over	28.45
Headlight buckets/pr	35.20
Body & left hand courtesy light harness	83.70
Taillight buckets/pr.....	30.80
Overdrive	109.45
Right hand courtesy light, quarter lamp switch & rear quarter lamps	69.95
Park light buckets/pr	21.00
Hood light wires.....	21.20
Front turn signal harness	31.00

Rear turn signal harness	28.65
Turn switch harness	27.45
Negative battery to starter cable.....	30.00
Positive battery to ground strap.....	18.20
Engine to frame strap	12.00

1950 HUDSON Commodore 6, Model 481 & 491

Cowl & engine	207.90
Drive-Master & overdrive	238.70
Misc. dash wires.....	22.25
Horn relay	46.65
Front turn signal connector	32.20
Generator to voltage regulator	18.35
Interior light w/ rear turn signal wires	105.50
Body	91.80
Negative battery to starter cable.....	30.00
Positive battery to ground strap	18.20
Engine to frame strap	12.00

1951 HUDSON

Drive-Master & overdrive.....	238.70
Body harness (RHD).....	109.05
Body harness (LHD).....	78.25
Overdrive w/o supermatic	61.60
Overdrive – voltage regulator to overdrive relay..	26.45
Forward turn signals.....	29.75
License light buckets/pr	39.40
Park & turn buckets/pr	38.35
Taillight cross-over harness	35.25
Signal flasher harness.....	29.50
Misc. wires	28.70
Right-hand cross-over & signal light buckets	7.50
Horn button wire	5.25
Dimmer switch & headlight harness	35.50
Headlight cross-over	52.15
Headlight buckets/pr	57.40
Rear power windows.....	159.20
Hydraulic dial indicator light harness	6.00

1952-53 HUDSON

Body – convertible	122.70
Body harness (RHD).....	109.05
Body harness (LHD).....	78.25
Headlight buckets/pr	57.40
Right-hand cross-over & signal lights	7.50
Headlight cross-over	52.15
Horn button wire.....	5.25
Signal indicator	20.65
Rear power windows harness.....	159.20
Hydraulic dial indicator light	7.50
Dimmer switch & headlight	35.50

1954 HUDSON

Cowl & engine	287.50
---------------------	--------

*Continued on next page.

1954 HUDSON – Continued

Body – conv	122.70
Taillight cross-over.....	32.05
Generator to voltage regulator	29.05
Dimmer switch & headlight	35.50
Headlight cross-over	52.15
Headlight buckets/pr	57.50
Signal indicator	20.65
Instrument lights.....	27.75
Left hand front power window.....	29.60
Rear power windows.....	159.20
Hydr. Dial indicator light	7.50
Convertible top switch to circuit breaker	6.00
Convertible circuit breaker to hydraulic pump sol.	7.00
Under dash junction block to forward signals.....	29.60

HUPMOBILE

1925 HUPMOBILE, Model R-14

Headlight harness..... stainless	74.45
Headlight harness..... cadmium	62.00
Body & taillight w/o brake light... stainless.....	89.00
Body & taillight w/o brake light.... cadmium	60.30
Body & taillight w/ brake light..... stainless.....	95.75
Body & taillight w/ brake light..... cadmium	70.70
Ammeter to starter switch..... stainless.....	20.15
Ammeter to starter switch..... cadmium	15.50
Light switch to ammeter..... stainless.....	26.35
Light switch to ammeter..... cadmium	18.70
Ammeter to dash light switch..... stainless	14.95
Ammeter to dash light switch..... cadmium	13.25
Horn feed wire..... stainless.....	22.15

*Continued on next page.

1925 HUPMOBILE, Model R-14 - continued

Horn feed wire..... cadmium	17.95
Negative battery cable..... stainless.....	44.75
Negative battery cable..... cadmium	40.35
Starter to starter switch cable..... stainless.....	26.70
Starter to starter switch cable..... cadmium	25.00

1925-26 HUPMOBILE Model A

Main lighting	147.20
Dash harness	68.75

1930-32 HUPMOBILE CENTURY SIX, Series 214

Main lighting.....	191.20
--------------------	--------

1930-32 HUPMOBILE, Models H & U, 225 & 237

Note: Please specify early or late? Early models have vacuum fuel gauge & late has electric.

Engine & dash (late)	85.80
Engine & dash (early).....	82.50
Body & horn (late)	78.95
Body & horn (early).....	74.10
Headlight harness	64.90

INTERNATIONAL

1929 INTERNATIONAL PICK-UP, 1 ½ Ton

Main lighting	stainless.....	177.90
Main lighting.....	cadmium	166.00
Positive battery cable.....		33.50
Battery to ground strap.....		20.25

1934-37 early INTERNATIONAL C-1 PICK-UP

Cowl, engine & main lighting.....	182.90
Misc. wires.....	48.00
Headlight buckets/pr.....	26.95
Heater harness.....	19.95

1940 INTERNATIONAL HARVESTER PICK-UP

Engine & headlight.....	41.30
Dash & engine	83.50
Taillight wire set.....	87.90
Headlight buckets/pr	41.75
Parking light buckets.....	30.85
Misc. dash & engine wires.....	35.70
Dome light wires	25.95
Windshield wiper harness	26.75
Positive battery cable.....	19.50
Negative battery cable.....	27.50
Starter battery cable	21.45

1941-46 INTERNATIONAL “K” TRUCK

Cowl, engine & headlight	217.80
Body	34.05
Headlight buckets/pr	32.30
Windshield wiper switch wires	15.60
Parking light wires/pr	7.80
Battery to starter cable	32.90
Heater harness	32.75
Horn button wires.....	11.95
Distributor to coil wire.....	4.30

1971 INTERNATIONAL TRACTOR

Engine harness	191.65
----------------------	--------

JEEP

1940-46 JEEP (WW II)

Trailer harness.....	109.60
----------------------	--------

KAISER

1949-50 KAISER SPECIAL & TRAVELER K-491, K-501 & DELUXE K-492 & K-502

Cowl, engine & headlight w/ turns.....	279.30
--	--------

*Continued on next page.

<u>1938-46 HARLEY-DAVIDSON Big Twin – Cont.</u>	
Headlight & horn feed	21.95
Generator to voltage regulator	28.80
Engine.....	30.70
Main harness	107.10

<u>1940 BSA MOTORCYCLE (WW II)</u>	
Main harness	108.35

<u>1946 SIMPLEX SERVICE CYCLE</u>	
Headlight	18.15
Taillight	22.90

<u>1952-55 HARLEY-DAVIDSON Model K</u>	
Wiring harness set	115.85

<u>1967 BSA SPITFIRE '650' MOTORCYCLE</u>	
Main harness	108.85
Distributor to coils	40.60

<u>1967 TRIUMPH BONNEVILLE TR-6 & T-120</u>	
Main harness	161.35

<u>1968 BSA MOTORCYCLE</u>	
Main harness – inquire	

NASH

<u>1926 NASH Light Six, Series 221</u>	
Engine & headlight.....	108.10
Cowl lights/pr.....	7.70
Cowl wires.....	6.00
Spark plug & coil wires.....	26.00

<u>1928 NASH Special Six, Model 341</u>	
Cowl & engine	99.10
Headlight harness	98.35
Headlight buckets/pr	57.40
Body	45.15
Dash harness	55.50
Distributor wires.....	12.25
Instrument panel light wires.....	8.60

<u>1929 NASH Special Six, Model 442</u>	
Cowl & engine	42.35
Fuse block – headlight switch	50.30
Headlight wires/pr.....	26.00
Misc. wires	22.60
Body	28.50
Spark plug & coil wires.....	28.00
Negative battery to starter motor cable	18.30

<u>1949 NASH "600", Series 4940 & Statesman 5040</u>	
Cowl, engine & headlight	261.00

<u>1954 NASH Rambler</u>	
Cowl, engine & headlight	214.75
Headlight buckets/pr	59.15
Body – 2 door sedan	130.15

OAKLAND

<u>1929 OAKLAND, 6 Cyl</u>	
Cowl, engine & headlight w/ misc. wires	104.50
Body	28.95
Cowl light buckets/pr	10.50
Horn harness	14.55

PACKARD

<u>1915-16 PACKARD Twin Six, 1st Series</u>	
Note: All original conduit junction boxes, ferrule ends & battery cable ends must be re-used.	
Headlight & engine kit..... cadmium	107.55
Headlight & engine kit..... stainless.....	129.50
Body harness kit..... cadmium	62.40
Body harness kit..... stainless.....	78.60
Positive battery – ground cable kit.. cadmium	55.20
Positive battery – ground cable kit.. stainless.....	73.15
Negative battery – starter cable..... cadmium	20.40
Negative battery – starter cable..... stainless.....	25.20

<u>1926-27 PACKARD 4TH Series, Model 426 & 433</u>	
Note: All original conduit junction boxes, ferrule ends & battery cable ends must be re-used.	
Main lighting..... cadmium	216.15
Main lighting..... stainless.....	266.75
Misc. dash & engine wires.....	21.45
Positive to ground cable.....	15.40
Negative battery to junction box cable	33.80
Junction box to starter switch cable.....	23.70
Starter switch to starter cable.....	14.30

<u>1927-28 PACKARD EIGHT, Model 443</u>	
Note: All original conduit junction boxes, ferrule ends & battery cable ends must be re-used.	
Cowl & body harness kit..... cadmium	221.65
Cowl & body harness kit..... stainless.....	261.25
Engine harness..... cadmium	35.75
Engine harness..... stainless.....	49.50
Taillight cross-over (optional)..... cadmium	44.25
Taillight cross-over (optional)..... stainless.....	55.85
Internal headlight wires – 3 wire.....	13.20
Solenoid to starter cable.....	22.50
Positive battery to ground cable.....	15.40
Negative battery to junction box cable	33.80
Starter switch to starter cable.....	14.30

1927-28 PACKARD Single Six 526

Note: All original conduit junction boxes, ferrule ends & battery cable ends must be re-used.

Main lighting kit.....cadmium	243.00
Main lighting kit.....stainless.....	285.00
Internal headlight wires – 3 wire.....	13.20
Taillight cross-over (optional).....cadmium	44.25
Taillight cross-over (optional).....stainless	55.85
Spark plug wires (oak).....	30.20
Positive battery to ground cable.....	15.40
Negative battery to junction box cable	33.80
Starter switch to starter cable.....	14.30
Junction box – starter switch cable.....	23.70

1927-28 PACKARD SIX 533

Note: All original conduit junction boxes, ferrule ends & battery cable ends must be re-used.

Main lighting..... cadmium	252.00
Main lighting..... stainless.	295.20
Internal headlight wires – 3 wire.....	13.20
Taillight cross-over (optional).....cadmium	44.25
Taillight cross-over (optional)..... stainless.....	55.85
Spark plug wires.....	30.20
Negative battery to junction box cable	33.80
Positive battery cable.....	15.40
Junction box to starter switch cable	23.70
Starter switch to starter cable.....	14.30

1929 early PACKARD Series 626

Note: Coil is located on the left.

Main lighting & cowl.....	240.50
Engine harness.	42.65
Accessory horn wires (wires for standard horn are in the main lighting harness)	32.80
Positive battery to ground cable	15.40
Junction box to starter switch cable	24.75
Starter switch to starter cable.....	14.30
Negative battery to junction block cable	33.80
Spark plug wires.....	29.70

1929 early PACKARD Series 633

Note: Coil is located on the left.

Main lighting	247.65
Engine harness	42.65
Accessory horn wires (wires for standard horn are in the main lighting harness).....	32.80
Spark plug wires.....	29.70
Positive battery to ground cable.....	15.40
Junction box to starter switch cable	24.75
Starter switch to starter cable.....	14.30
Negative battery to junction block	33.80

1929 late PACKARD Series 626

Note: Coil is located on the right.

Main lighting	245.70
---------------------	--------

Engine harness	46.20
Accessory horn wires (wires for standard horn are located in the main harness.)	32.80
Positive battery to ground cable	15.40
Junction box to starter switch cable	24.75
Starter switch to starter cable	14.30
Negative battery to junction block.....	33.80
Spark plug wires.....	29.70

1929 late PACKARD Series 633

Note: Coil is located on the right.

Main lighting.....	252.40
Engine harness	46.20
Accessory horn wires (wires for standard horn are located in the main lighting harness.)	32.80
Spark plug wires.....	29.70
Positive battery to ground cable.....	15.40
Junction box to starter switch cable	24.75
Starter switch to starter cable	14.30
Negative battery to junction block	33.80

1929 early PACKARD Series 640

Note: Coil is located on the left.

Main lighting.....	231.00
Main lighting (optional wires).....	254.10
Engine harness	44.80
Accessory horn wires (wires for standard horn are located in the main lighting harness.)	32.80
Spark plug wires.....	29.70
Positive ground cable	15.40
Junction box to starter switch cable	24.75
Starter switch to starter	17.25
Negative battery to junction block.....	17.50

1929 late PACKARD Series 640

Note: Coil is located on the right.

Main lighting	235.20
Main lighting (optional wires).....	258.72
Engine.....	50.40
Accessory horn wires (wires for standard horn are located in the main lighting harness.)	32.80
Spark plug wires.....	29.70
Positive ground cable	15.40
Junction box to starter switch cable	24.75
Starter switch to starter.....	17.25
Negative battery to junction block	17.50

1929 early PACKARD Series 645

Note: Coil is located on the left.

Main lighting.....	240.65
Engine harness	44.80
Accessory horn wires (wires for standard horn are included in the main lighting harness.).....	32.80
Spark plug wires.....	29.70
Positive ground cable	15.40
Junction box to starter switch cable	24.75

Starter switch to starter	14.30
Negative battery to junction block	33.80
<u>1929 late PACKARD Series 645</u>	
Note: Coil is located on the right.	
Main lighting	244.25
Engine harness.....	50.40
Accessory horn wires (wires for standard horn are included in the main lighting harness.)	32.80
Spark plug wires.....	29.70
Positive ground cable	15.40
Junction box to starter switch cable	24.75
Starter switch to starter	14.30
Negative battery to junction block	33.80

1930 PACKARD Model 726

Main lighting	275.00
Engine & ignition harness.....	36.65
Misc. dash wires.....	4.00
Spark plug & coil wires.....	29.70
Positive battery to ground cable.....	15.40
Negative battery to junction box cable	33.80
Starter switch to starter	14.30
Junction box to starter switch	24.75

1930 PACKARD Model 733 & 734

Main lighting	295.00
Engine & ignition wires.....	36.55
Misc. dash wires.....	4.00
Spark plug & coil wires.....	29.70
Positive battery to ground cable.....	15.40
Negative battery to junction box cable	33.80
Starter switch to starter	14.30
Junction box to starter switch.....	24.75

1930 PACKARD Custom 740

Main lighting.....	297.00
Engine & ignition harness.....	39.60
Misc. dash wires.....	4.00
Spark plug & coil wires.....	29.70
Positive battery to ground cable	15.40
Negative battery to junction box cable	33.80
Junction box to starter switch cable	23.70
Starter switch to starter cable	40.75

1930 PACKARD Deluxe 745

Main lighting..... cadmium	298.75
Main lighting..... stainless.....	308.00
Engine & ignition harness.....	39.60
Misc. dash wires.....	4.00
Spark plug & coil wires.....	29.70
Positive battery to ground cable.....	15.40
Negative battery to junction box cable	33.80
Junction box to starter switch cable	24.75
Starter switch to starter cable	40.75

1931 PACKARD Model 826 & 833

Main lighting.....	217.15
Engine & ignition harness.....	47.35
Taillight cross-over (optional)	29.85
Accessory dual horn harness.....	33.50
Positive battery to ground cable.....	15.40
Negative battery to junction box cable	33.80
Junction block to starter switch cable.....	23.70
Spark plug wires.....	29.75

1931 PACKARD Model 840

Main lighting	217.15
Engine & ignition harness.....	47.35
Tail light cross-over harness (optional)	29.85
Accessory dual horn harness.....	33.50
Positive battery to ground cable	15.40
Negative battery to junction box cable	33.80
Junction block to starter switch cable.....	23.70
Starter switch to starter	31.00
Spark plug wires.....	29.75

1931 PACKARD Model 845

Main lighting.....	217.15
Engine & ignition harness.....	47.35
Taillight cross-over (optional)	29.85
Accessory dual horn harness.....	33.50
Positive battery to ground cable.....	15.40
Negative battery to junction box cable	33.80
Starter switch to junction box cable	26.10
Spark plug wires.....	29.75

1932 PACKARD Light Eight 900

Main lighting	370.95
Electric starter switch harness	47.25
Reading light wires.....	5.00
Engine harness	38.85
Taillight cross-over.....	15.40
Cigar lighter wire	4.65
Headlight buckets/pr	23.05
Taillight buckets/pr.....	12.55
Horn button to horn wire	6.35
Gas gauge to coil base wire	4.95
Junction box to starter switch cable	23.70
Starter switch to starter cable	16.90
Positive battery to ground cable	18.20
Negative battery to starter cable.....	47.85
Spark plug wires.....	29.70

1932 PACKARD Standard Eight 901 & 902

Main lighting.....	389.70
Engine harness	38.85
Headlight buckets/pr	23.05
Taillight buckets/pr	12.55
Taillight cross-over wires	16.80
Steering column horn wire.....	6.35

Gas gauge to coil base wire	4.95
Reading light wires.....	5.00
<u>1932 PACKARD Standard Eight 901 & 902 – Cont.</u>	
Junction box to starter switch cable	23.70
Starter switch to starter cable	16.90
Positive battery to ground cable	18.20
Negative battery to starter cable.....	47.85
Spark plug wires.....	29.70

1932 PACKARD Deluxe Eight 903 & 904

Main lighting.....	402.70
Engine harness	38.85
Headlight buckets/pr	23.05
Taillight buckets/pr.....	12.55
Taillight cross-over.....	16.80
Reading light wire	5.00
Horn button wire	6.35
Spark plug wires.....	29.70
Junction box to starter switch cable	23.70
Starter switch to starter cable	16.90
Positive battery to ground cable.....	18.20
Negative battery to starter cable.....	20.40

1932 PACKARD, Series 905 & 906

Cowl & engine	135.00
Headlight harness	157.35
Headlight, park light & fender light buckets.....	41.00
Body (142" wheel base)	115.00
Body (147" wheel base)	119.50
Starter harness	39.50
Instrument light cluster	29.30
Spark plug wires.....	39.00
Negative battery to starter switch cable	49.00
Positive battery to ground cable.....	14.40

1933 PACKARD Eight 1001 & 1002

Cowl & engine	155.00
Headlight, park light, & fender light buckets.....	41.00
Headlight harness	172.55
Body (1001)	121.50
Instrument light cluster harness	29.30
Spark plug wires.....	35.00

1933 PACKARD Super Eight 1003 & 1004

Cowl & engine	145.35
Headlight harness	110.15
Body (1003)	100.80
Body (1004)	110.85
Instrument light cluster harness.....	29.30
Headlight, park light & fender light buckets.....	45.00
Spark plug wires.....	29.70

1933 PACKARD Twelve 1005 & 1006

Cowl & engine	135.00
---------------------	--------

Headlight harness	157.35
Headlight, park light & fender light buckets	41.00
Body (1005)	115.00
Body (1006)	119.50
Starter harness.....	39.50
Instrument light cluster harness	29.30
Spark plug wires.....	39.00
Negative battery to starter switch cable	49.00
Positive battery to ground cable.....	14.40

1934 PACKARD Standard Eight 1100, 1101 & 1102

Cowl, engine & main lighting	471.90
Steering column horn wire	8.25
Spark plug wires.....	35.00
Negative battery cable.....	46.65
Positive battery strap	22.50
Startix wires	42.35

1934 PACKARD Super Eight 1103, 1104 & 1105

Cowl, engine & main lighting	474.70
Steering column horn wire	8.25
Spark plug wires.....	37.50
Startix wires	42.35
Negative battery cable	46.65
Positive battery strap	22.50

1934 PACKARD Twelve 1106, 1107 & 1108

Cowl, engine & main lighting	468.00
Starter solenoid to ammeter	45.00
Steering column horn wires	8.25
Startix wires	42.35
Spark plug wires.....	48.00
Negative battery cable.....	50.60
Positive battery cable.....	16.50
Positive battery strap (1106)	21.40
Ground strap (1106)	10.95

1935 PACKARD Eight 1200

Main lighting harness.....	396.00
Negative battery cable	64.15
Positive battery cable.....	25.85

1935 PACKARD Eight 1201 (RHD)

Cowl & headlight harness	276.00
Body	221.05
Negative battery cable	64.15
Positive battery cable.....	25.85

1935 PACKARD Super Eight 1204 & 1205

Positive battery cable	27.50
------------------------------	-------

1935 PACKARD Twelve 1207

Negative battery to starter switch cable	64.35
Positive battery to ground strap.....	21.80

1936 PACKARD Model 120

Cowl, engine & main lighting	403.00
Headlight buckets/pr	37.10
Taillight buckets/pr	27.85
Radio feed & fuse	13.50
Clock feed & fuse	14.00
Cigarette lighter feed wire	4.00
Spark plug wires.....	36.00
Negative battery cable.....	40.00

1936 PACKARD Standard Eight 1400, 1401 & 1402

Cowl, engine & main lighting	469.00
Coil to ignition switch wire	11.80

1936 PACKARD Super Eight 1403, 1404 & 1405

Cowl & main lighting.....	485.40
Negative battery cable	52.00
Interior light wires	25.30

1936 PACKARD Twelve 1407 & 1408

Cowl, engine & main lighting	471.00
Starter harness	43.55
Interior light wires.....	25.30

1937 PACKARD 110 Model 115C

Note: Early has 2 wire generator & late has 3 wire generator.

Cowl, engine, headlight & body (early).....	312.00
Cowl, engine, headlight & body (late)	324.00
Headlight buckets/pr	60.00
Taillight buckets/pr	31.90
Coil to distributor.....	10.50
Instrument lights.....	25.95
Electric windshield harness	17.95
Horn relay	16.55

1937 PACKARD 120 Model 120CD

Note: Early has 2 wire generator & late has 3 wire generator.

Cowl, engine, headlight & body (early).....	316.25
Cowl, engine, headlight & body (late).....	330.00
Headlight buckets/pr	60.00
Taillight buckets/pr.....	31.90
Coil to distributor wire.....	10.50
Instrument lights.....	25.95
Electric windshield harness	17.95
Horn relay	16.55

1937 PACKARD Super Eight 1500, 1501 & 1502

Cowl, engine, headlight & body (1500).....	311.00
--	--------

Cowl, engine, headlight & body (1501).....	316.75
Cowl, engine, headlight & body (1502).....	319.00
Headlight buckets/pr	60.00
Headlight indicator harness	18.75
Taillight buckets/pr.....	31.90
Instrument & reading light harness	16.00
Coil to distributor wire	10.50
Horn wire	6.00
Negative battery to starter solenoid cable	42.00
Positive battery to ground strap	15.00

1937 PACKARD Twelve 1506, 1507 & 1508

Cowl, engine & headlight	310.50
Body (1506)	142.20
Body (1507)	146.60
Body (1508)	152.80
Headlight buckets/pr	60.50
Headlight & park light indicator lights.....	18.75
Steering column horn button wire.....	6.00
Taillight buckets/pr.....	31.90
Coil to distributor wire	10.50
Starter & negative battery cable.....	91.00
Positive battery to ground strap	18.00
Engine to ground strap	9.00

1938 PACKARD Six 1600

Cowl, engine & headlight w/o overdrive	257.05
Headlight buckets/pr	53.00
Body	78.50
Taillight buckets & cross-over	44.60
Clock & glove box wiring	23.75
License light & trunk harness.....	9.30
Dash lights & misc. wires	46.20
Turn signal flasher harness.....	26.85
Turn switch harness	44.30
Engine to ground strap	9.00
Negative battery to starter switch	46.80
Positive battery to ground strap.....	15.60

1938 PACKARD '120' Eight, Models 1601, 1601A & 1602

Cowl, engine & headlight w/o overdrive	259.95
Headlight buckets/pr	53.00
Taillight buckets & cross-over	44.60
Dash lights & misc. wires	46.20
Body harness	78.50
License light & trunk wires	9.30
Clock & glove box harness	23.75
Turn signal flasher harness	26.85
Turn signal switch harness.....	26.85
Engine to ground strap	9.20
Negative battery to starter switch cable	46.80
Positive battery to ground strap	15.60

1938 PACKARD Super Eight, Models 1603, 1604 & 1605

Cowl, engine & headlight w/o overdrive 276.30
*Continued on next page.

1938 PACKARD Super Eight, Models 1603, 1604 & 1605 – continued

Headlight buckets/pr 49.45
Body 104.25
Taillight buckets/pr 32.35
Taillight cross-over..... 27.75
Dome light wire 9.30
Clock & glove box light harness 23.75
Turn signal flasher harness..... 26.85
Turn signal switch harness 44.30
Engine to ground strap 9.20
Negative battery to starter switch cable 46.80
Positive battery to ground strap 15.60

1938 PACKARD Twelve, Models 1607 & 1608

Cowl, engine & headlight w/o overdrive 308.75
Headlight buckets/pr 49.95
Body harness 110.00
Taillight buckets/pr 32.25
Taillight cross-over..... 27.25
Dome light switch wires..... 9.30
Clock & glove box light harness 23.75
Turn signal flasher harness..... 26.85
Turn signal switch harness..... 44.30
Negative battery to starter switch cable 60.00
Positive battery to ground strap..... 15.60
Engine to ground strap 9.20
Spark plug wires..... 51.35

1939 PACKARD Six 1700

Cowl, engine & headlight w/ overdrive 280.15
Headlight buckets/pr 53.00
Body harness 78.50
Taillight buckets & cross-over 44.60
Clock & glove box wires 23.75
License light & trunk harness..... 9.30
Dash lights & misc. wires 46.20
Turn signal flasher harness..... 26.85
Turn signal switch harness 44.30
Engine to ground strap 9.00
Negative battery to starter switch 46.80
Positive battery to ground strap 15.60

1939 PACKARD ‘120’ Eight, Models 1701, 1701A, & 1702

Cowl, engine & headlight w/ overdrive 276.15
Cowl, engine & headlight w/ overdrive (Darrin).. 285.85
Headlight buckets/pr 53.00
Taillight buckets & cross-over 44.60
Dash lights & misc. wires 46.20
Body harness 78.50
License light & trunk wires 9.30

Clock & glove box light harness 23.75
Turn signal flasher harness 26.85
Turn signal switch harness..... 44.30
Engine to ground strap 9.20
Negative battery to starter switch cable 46.80
Positive battery to ground strap 15.60

1939 PACKARD Super Eight, Models 1703, 1703A & 1705

Cowl, engine & headlight 225.00
Headlight buckets/pr 49.45
Body harness 104.25
Taillight buckets/pr..... 32.35
Taillight cross-over 27.75
Dome light wire..... 9.30
Clock & glove box light harness 23.75
Turn signal flasher harness 26.85
Turn signal switch harness..... 44.30
Engine to ground strap 9.20
Negative battery to starter switch cable 46.80
Positive battery to ground strap..... 15.60

1939 PACKARD Twelve, Models 1707 & 1708

Cowl, engine & headlight w/o overdrive 308.75
Headlight buckets/pr 49.95
Body harness 110.00
Taillight buckets/pr..... 32.25
Taillight cross-over..... 27.25
Dome light switch wires..... 9.30
Clock & glove box light harness 23.75
Turn signal flasher harness 26.85
Turn signal switch harness 44.30
Positive battery to ground strap..... 15.60
Engine to ground strap 9.20
Negative battery to starter switch cable 60.00
Spark plug wires..... 51.35

1940 PACKARD ‘110’, Model 1800

Cowl, engine & headlight w/o overdrive 262.00
Cowl, engine & headlight w/o overdrive w/ opts.. 314.00
Overdrive harness 109.20
Overdrive connector harness..... 46.25
Headlight buckets/pr 75.70
Clock & glove box harness 26.75
Windshield wiper harness (1 speed)..... 35.15
Windshield wiper harness (2 speed) 38.65
License plate & trunk wires 9.30
Body harness 87.75
Body w/ options..... 105.75
Park light buckets/pr 23.40
Taillight buckets/pr 47.00
Horn & starter solenoid wires..... 14.00
Coil wires 9.55
Dome light wires 10.00
Turn signal flasher harness..... 29.55
Turn signal switch harness 48.75

Negative battery to starter switch cable.....	39.00
Positive battery to ground strap.....	15.60

1940 PACKARD '120', Model 1801

Cowl, engine & headlight	265.00
Cowl, engine & headlight w/ options.....	317.00
Body harness	87.75
Body w/ options.....	105.75
Overdrive harness.....	109.20
Overdrive connector harness.....	46.25
Headlight buckets/pr	75.70
Park light buckets/pr	23.40
Clock & glove box harness	26.75
License plate & trunk wires	9.30
Taillight buckets/pr.....	47.00
Windshield wiper harness (1 speed)	35.15
Windshield wiper harness (2 speed).....	38.65
Horn & steering column wires	14.00
Turn signal flasher harness.....	29.55
Turn signal switch harness.....	48.75
Spark plug wires.....	35.00
Negative battery to starter switch cable	39.00
Positive battery to ground	16.00

1940 PACKARD '160', Model 1803, 1804 & 1805

Cowl, engine & headlight	342.80
Cowl, engine & headlight w/ options.....	410.80
Headlight buckets/pr	75.70
Park light buckets/pr	23.40
Body harness	87.75
Body w/ options	105.35
Overdrive harness	109.20
Overdrive connector harness	46.25
Clock & glove box harness.....	26.75
License plate & trunk wires	11.30
Taillight buckets/pr.....	47.00
Windshield wiper harness (1 speed)	35.15
Horn & steering column wire.....	14.00
Turn signal flasher harness.....	29.55
Turn signal switch harness	48.75
Spark plug wires.....	35.00
Negative battery cable (Darrin)	53.00
Negative battery to starter switch cable	39.00
Positive battery to ground	16.00
Heater motor harness	37.75

1940 PACKARD '180', Model 1806, 1807 & 1808

Cowl, engine & headlight	342.80
Cowl, engine & headlight w/ options.....	411.30
Headlight buckets/pr.....	75.70
Park light buckets/pr.....	23.40
Body harness	87.75
Body w/ options	105.75
Taillight buckets/pr	48.10
Overdrive	109.20
Overdrive connector harness.....	46.25
Clock & glove box harness.....	26.75

License plate & trunk wires	11.30
Windshield wiper harness (1 speed)	35.15
Horn & steering column wire.....	14.00
Turn signal flasher harness.....	29.55
Turn signal switch harness.....	48.75
Spark plug wires.....	35.00
Negative battery cable (Darrin)	53.00
Negative battery to starter switch cable.....	39.00
Positive battery to ground	16.00
Heat motor harness – 4 wire	37.75

1941 PACKARD '110', Model 1900

Cowl, engine & headlight w/o overdrive	284.00
Cowl, engine & headlight w/o overdrive w/ opt... ..	340.80
Headlight, park light & turn wires/pr	70.95
Body harness	91.45
Body w/ options	100.60
Electromatic clutch harness	127.10
Electromatic clutch connector harness.....	66.00
Clock & glove box harness	34.30
Park light buckets/pr	24.00
Taillight buckets/pr	47.00
Taillight buckets w/ turns/pr	51.70
Electric windshield wiper harness.....	38.70
Turn signal flasher harness.....	29.55
Turn signal switch harness	48.75
Overdrive harness	109.20
Overdrive connector harness.....	46.25
Courtesy light harness.....	35.60
Radio lead w/ fuse wire.....	10.65

1941 PACKARD '120', Model 1901

Cowl, engine & headlight w/o overdrive	258.00
Cowl, engine & headlight w/o overdrive w/ opts.. ..	310.00
Cowl, engine & headlight w/ overdrive	382.10
Cowl, engine & headlight w/ overdrive & options	458.50
Body harness.....	83.15
Body w/ options.....	99.75
Electric clutch connector harness.....	60.00
Electric clutch harness.....	115.55
Headlight buckets w/ park light & turn wires.....	66.95
Clock & glove box.....	34.30
Park light buckets/pr	21.00
Taillight buckets/pr.....	37.00
Taillight buckets w/ turns/pr	44.50
Electric windshield wiper harness.....	35.20
Turn signal flasher harness.....	26.85
Turn signal switch harness	44.30
Overdrive connector harness.....	52.25
Overdrive harness.....	109.20
Courtesy light harness.....	32.35
Radio lead w/ fuse	9.65
Heater wires	21.55
Chassis to transmission strap.....	15.85

1941 PACKARD '160' Super Eight, Models 1903, 1904 & 1905 & '180' Custom Super Eight, Models 1906, 1907 & 1908

Cowl, engine & headlight w/o overdrive	242.05
Cowl, engine & headlight w/o overdrive w/ opts..	290.45

*Continued on next page.

1941 PACKARD '160' Super Eight & Custom Super Eight – continued

Cowl, engine & headlight w/ overdrive	281.40
Cowl, engine & headlight w/ overdrive & opts. ..	337.70
Body harness (127" wb).....	82.40
Body w/ options (127" wb).....	98.90
Body harness (138" wb).....	85.80
Body w/ options (138" wb)	103.00
Body harness (148" wb).....	91.00
Body w/ options (148" wb)	109.00
Electric clutch connector harness.....	60.00
Electromatic clutch harness	115.55
Headlight buckets w/ park light & turn wires/pr...	66.95
Clock & glove box wires	34.30
Park light buckets/pr	21.00
Driver's door power window harness.....	51.60
Taillight buckets/pr.....	37.50
Taillight buckets w/ turns/pr	44.50
Electric windshield wiper harness.....	35.20
Turn signal flasher harness.....	26.85
Turn signal switch harness	44.30
Overdrive connector harness	46.25
Overdrive harness	109.20
Hydraulic window solenoid to hydraulic pump motor cables	20.85
Starter solenoid to power window pump solenoid	7.95
Courtesy light harness.....	32.35
Radio lead wire w/ fuse.....	9.65
Negative battery cable	50.00

1941 PACKARD CLIPPER, Model 1951

Cowl, engine & headlight	273.15
Cowl, engine & headlight w/ options.....	327.75
Headlight buckets/pr	67.75
Headlight buckets w/ options/pr	81.30
Body harness (4 door)	100.30
Body w/ options (4 door)	136.00
Taillight buckets/pr.....	51.80
Taillight buckets w/ options/pr	62.15
Interior body – lights & cigar lighters (4 door)....	104.65
Body & interior lights harness #1	116.75
Interior lights harness #2.....	38.15
Electric windshield wiper harness.....	42.90
Under seat heater & fresh air harness.....	26.80
Park light buckets/pr	27.15
Park light buckets w/ options/pr.....	32.58
License light wire	6.85
Spot light – armoured	8.95
Clock harness	28.75

1942 PACKARD '110' Six, Clipper Models 2000 & 2010

Cowl, engine & headlight w/o overdrive	244.55
Cowl, engine & headlight w/ overdrive	269.00
Headlight harness/pr.....	83.60
Body harness	76.30
Overdrive harness	93.75
Overdrive connector harness.....	43.60
Instrument light wires.....	13.20
Park & turn bucket wires/pr	17.40
Clock & glove box wires	27.95

1942 PACKARD '120' Clipper, Models 2001 & 2011

Cowl, engine & headlight	265.80
Body	92.35
Taillight buckets/pr.....	52.00
Trunk, license & back-up lights	42.45
Courtesy light harness.....	40.80
Headlight buckets w/ park light & turns.....	79.30
Fog light harness & related wires.....	31.50
Overdrive connector harness.....	39.50
Overdrive harness.....	94.65
Instrument light wires.....	13.20
Clock & glove box wires	27.95

1942 PACKARD '160' Super Clipper Eight, Models 2003, 2003A, 2004, 2005 & 2055 & '180' Custom, Models 2006 & 2007

Cowl, engine & headlight w/o overdrive	260.90
Cowl, engine & headlight w/ overdrive	296.90
Overdrive harness	93.75
Overdrive connector harness.....	43.60
Park & turn light buckets/pr	17.40
Headlight harness/pr	83.60
Body harness	76.30
Clock & glove box harness	27.95
Instrument light wires.....	13.20
Electromatic clutch harness.....	99.75
Negative battery cable.....	48.50

1942 PACKARD '180' Limousine w/ turns, Model 2008

Cowl, engine & headlight w/o overdrive	321.60
Body (148" wb).....	96.50
Park & turn light buckets/pr	17.40
Headlight harness/pr.....	83.60
Taillight buckets/pr.....	48.95
Electromatic clutch	99.75
Clock & glove box harness	27.95
Instrument light wires.....	13.20

1946-47 PACKARD Clipper Six 2100 & Taxi cab 2130

Cowl, engine & headlight w/o overdrive	291.80
Cowl, engine & headlight w/ overdrive	316.25
Body harness	103.95

Clock & glove box harness.....	27.95
Instrument light harness.....	13.20
Headlight buckets/pr	83.60
Overdrive connector harness.....	43.60
Overdrive harness.....	93.75

1946-47 PACKARD Super & Custom Clipper Eight, Models 2103, 2106, 2123 & 2126

Cowl, engine & headlight w/o overdrive & electric clutch	291.50
Cowl, engine & headlight w/ overdrive & electric clutch	357.00
Cowl, engine & headlight w/ overdrive	316.00
Cowl, engine & headlight w/ electric clutch.....	302.50
Body (2106)	80.30
Left-hand taillight & right-hand cross-over & tail-light (2106)	51.70
Taillight buckets & cross-over (2126)	37.75
Headlight buckets/pr	83.60
Overdrive harness.....	93.75
Overdrive connector harness.....	43.60
Park light & turn buckets/pr	14.40
Instrument light wires.....	13.20
Clock & glove box harness.....	27.95
Front seat courtesy light harness (2106 & 2126) ..	55.60
Rear seat courtesy light harness (2106 & 2126) ..	81.55
Negative battery cable (Custom Eight).....	25.30

1946-47 PACKARD Deluxe Clipper Eight, Models 2111 & 2101

Cowl, engine & headlight w/ turns.....	316.25
Body harness	103.95
Clock & glove box harness.....	27.95
Instrument light wires.....	13.20
Park & turn buckets/pr	14.40
Headlight buckets/pr	83.60
Overdrive connector harness.....	43.60
Overdrive harness	93.75
Negative battery cable	30.40

1948-49 early PACKARD (R9 overdrive system) 22nd Series

Cowl, engine & headlight	399.75
Cowl, engine & headlight w/ overdrive	431.75
Cowl, engine & headlight w/ overdrive & electric clutch	477.60
Overdrive & electric clutch harness (for customers who already have cowl, engine & headlight installed.).....	109.75
Overdrive harness	82.25
Body harness (station wagon).....	95.45
Taillight buckets/pr (station wagon)	23.25
Headlight buckets/pr	43.75
Park light & turn buckets/pr	31.30
Horn harness.....	9.75
Ignition switch to heater switch	9.55

Overdrive & electric clutch connector harness	42.60
Overdrive connector harness.....	37.20
Taillight harness w/ turns & back-up lights	24.65
Rear seat lights & cigar lighter.....	20.25
Spark plug wires (8 cyl)	27.00
Negative battery to starter switch cable	17.60
Positive battery to generator ground cable.....	23.90

1948-50 PACKARD, Model 2201-9

Cowl, engine & headlight (Hercules station wagon).....	478.50
Overdrive harness (R11)	103.40

1949 late – 50 PACKARD

Cowl, engine & headlight	492.00
Cowl, engine & headlight w/ overdrive	567.50
Cowl, engine & headlight w/ electric clutch.....	546.00
Cowl, engine & headlight w/ overdrive & electric clutch	594.00
Headlight buckets/pr	44.15
Park light buckets/pr.....	34.75
Horn relay to dual horns.....	17.60
Taillight harness	33.25
Body	115.30
Overdrive harness (R11)	103.40
Negative battery to mag starter switch cable	19.35
Positive battery to generator ground cable.....	26.30

1949-50 PACKARD Custom Eight Convertible, Series 2359-5, 2306, 2333, 2306-5 & 2333-5

Note: Harnesses require transfer time.

Cowl, engine & headlight	426.00
Headlight buckets/pr	52.25
Horn harness	17.50
Body	116.40
Taillight buckets/pr.....	26.45
Power window, seat & top harness.....	284.35
Power window & seat.....	275.50
Starter solenoid to hydraulic pump.....	22.60
Radio wire	6.00
Heater switch feed harness.....	9.00
Park & turn buckets/pr	38.00

1951 PACKARD, Series 300

Cowl, engine & headlight	395.00
Headlight buckets/pr	46.95
Headlight cross-over	59.40
Body harness	114.95
Power antenna harness	63.90

1951 PACKARD Patrician 400, Model 2406

Cowl, engine & headlight w/ turns.....	420.30
Headlight buckets/pr	47.00
Body w/ turns	110.15
Headlight, park light & horn cross-over w/ turns..	43.80
Interior wires	45.75

Spark plug wires (8 cyl)	35.10
Negative battery to starter cable	30.25
Positive battery to ground cable	28.45

1953 PACKARD Convertible, Series 300

Body harness	178.40
Headlight buckets/pr	42.75
Park light buckets/pr	25.05
Conv. top pump cable	14.10
License plate light wire	9.65
Glove box light wire	12.55
Headlight & horn cross-over	63.55
Convertible top pump harness	40.25
Back-up light wires	33.95
Heater blower switch wire	18.55
Gas sender wire	11.55
Ground strap	17.80
Spark plug wires (8 cyl)	35.10
Negative battery to starter cable	27.50

1953 PACKARD Patrician 400, Model 2606

Cowl, engine & headlight	458.40
Cowl, engine & headlight	465.15
Back-up light switch wires	12.95
Spark plug wires (8 cyl)	35.10
Negative battery to starter cable	27.50
Positive battery to ground	25.85

1953 PACKARD Caribbean, Model 2631, Type 2678

Cowl, engine & headlight	430.10
--------------------------------	--------

1954 PACKARD Caribbean Convertible

Cowl, engine & headlight w/ turns	476.90
Body harness	210.40
Power window harness	264.70
Misc. wires	30.45
Pump solenoid to seat switch	9.10
Hydraulic pump battery cable & ground strap	15.80
Spark plug wires	27.00
Negative battery to starter solenoid cable	27.50
Positive battery to ground cable	25.85

1955 PACKARD

Park & turn light buckets/pr	27.00
Headlight buckets/pr	29.00
Negative battery to starter cable	28.50
Positive battery to ground cable	19.50

1956 PACKARD

Park light & turn buckets/pr	27.00
Headlight buckets/pr	29.00

PIERCE ARROW

1928 PIERCE ARROW, Model 81

Cowl & engine	50.85
Misc. dash & engine wires	17.40
Dome light switch wires	7.50

1929 PIERCE ARROW, Models 133 & 140

Main harness kit	stainless	313.75
Main harness kit	cadmium	254.35
Headlight buckets/pr	stainless	43.00
Headlight buckets/pr	cadmium	36.30
Headlight cross-over	stainless	26.95
Headlight cross-over	cadmium	21.45
Taillight buckets/pr	stainless	25.75
Taillight buckets/pr	cadmium	21.60
Ignition light & misc. dash wires		13.20
Instrument light cluster		19.80
Coil & instrument light feed		9.35

1932 PIERCE ARROW, Models 51, 52, 53 & 54

Main lighting harness	223.60
Dash harness	37.80
Headlight, park light & horn cross-over	43.80
Headlight & park light buckets/pr	60.40

1933 PIERCE ARROW, Model 1236 & 1247

Cowl, engine & headlight	231.60
Body (1247)	88.85
Body (1236)	89.10
Taillight buckets/pr	52.15

1934 PIERCE ARROW, Model 8-36A

Headlight & engine	179.40
Body	64.90
Taillight buckets/pr	57.95
Electric choke & distributor wires	17.50

1936-38 PIERCE ARROW, Models 1601, 1701 & 1801

Cowl to junction box	188.40
Headlight & engine	196.45
Body	132.15
Clock & glove box harness	23.05
Neutral startix safety switch harness	14.55

REO

1919 REO, Model 'F'

Cowl & engine	100.75
Headlight buckets/pr	44.55
Body harness	55.45

Positive battery cable	27.60
Negative battery cable.....	26.40

..... stainless	34.20
Starter switch to starter cable.. cadmium	40.15
Starter switch to starter cable.. stainless	52.50

RICKENBACKER

1925 RICKENBACKER, Series D (Roadster)

Cowl, engine & headlight.....cadmium....	124.00
Cowl, engine & headlight.....stainless	133.00
Body.....cadmium....	84.60
Body.....stainless...	100.20

STEARNS KNIGHT

1929 STEARNS KNIGHT, 4 door Sedan

Junction block to fuse block	127.60
Junction block, headlight switch, horn & body....	226.45
Engine & headlight harness	86.65
Misc. dash wires.....	30.45
Starter switch & coil harness.....	24.00
Cowl lights harness.....	15.60
Misc. engine wires.....	8.60

STUDEBAKER

1922 STUDEBAKER Light Six, Model EJ

Note: All original conduit ferrule ends must be re-used.

Cowl & engine..... cadmium	118.50
Cowl & engine..... stainless	133.50
Headlight buckets/pr.....	28.15
Side lights/pr.....	20.90
Misc. wires (6).....	62.65
Positive battery cable.....	18.75
Negative battery to starter cable.....	22.85

1923-24 STUDEBAKER Light Six, Model EM

Note: All original conduit ferrule ends must be re-used.

Cowl & engine..... cadmium	118.50
Cowl & engine..... stainless	133.50
Headlight buckets/pr.....	28.15
Side lights/pr.....	20.90
Misc. wires.....	62.65
Positive battery cable to frame.....	18.75
Negative battery to starter cable.....	22.85

1926-27 STUDEBAKER, Models EP, EQ, ES & EW

Cowl, engine & main lighting.. cadmium	239.80
Cowl, engine & main lighting.. stainless	263.80
Negative battery to starter switch cable	
..... cadmium	33.00

1926-27 STUDEBAKER Standard Six, Models ER & EU

Cowl, engine & main lighting.. cadmium	231.00
Cowl, engine & main lighting.. stainless	249.60
Coil to distributor cap wire.....	3.00
Starter switch to starter cable.. cadmium	34.65
Starter switch to starter cable.. stainless	40.15
Negative battery to starter switch	30.10

1928 STUDEBAKER Commander & President

Battery to ground strap.....	16.80
------------------------------	-------

1928 STUDEBAKER Dictator Eight, Model FC

Battery to starter switch cable (6 cyl).....	27.75
Starter switch to starter motor cable (8 cyl)	20.85

1929-30 STUDEBAKER Dictator, Models GL & GJ

Main lighting.....	157.30
Spark plug wires.....	30.00
Battery to starter switch cable (8 cyl).....	34.35
Battery to starter switch cable (1929 early, 6 cyl).	27.75
Battery to starter switch cable (1929 late - 30, 6 cyl)	37.85
Battery to ground strap (6 cyl)	15.60

1929-30 STUDEBAKER President, Models FE & FH

Note: All original conduit ferrule ends must be re-used.

Main lighting..... cadmium	221.75
Main lighting..... stainless	252.25
Taillight buckets/each.....	13.20
Dash wire.....	8.25
Battery to ground strap.....	16.80
Battery to starter switch cable.....	24.35
Spark plug wires (8 cyl).....	30.00

1929-30 STUDEBAKER Commander, Model GJ

Battery to ground strap.....	15.60
Battery to starter switch cable (1929 only, 6 cyl) .	34.90
Battery to starter switch cable (1930 after Body #8,030,823).....	27.75
Battery to starter switch cable (8 cyl).....	31.35
Spark plug wires (8 cyl).....	30.00

1930 STUDEBAKER, Model S1

Battery to starter switch cable.....	45.90
Spark plug wires (8 cyl).....	30.00

1931 STUDEBAKER, Model 53 & 54

Cowl & engine 146.65
Headlight & body 147.35

*Continued on next page.

1931 STUDEBAKER, Model 53 & 54 - Continued

Headlight wires 20.15
Battery to starter switch cable (1953)..... 45.90
Battery to starter switch cable (1954)..... 25.70
Positive battery to ground strap..... 16.95

1931 STUDEBAKER Dictator

Positive battery to ground strap 16.95
Negative battery to starter switch cable (before #
9,005,625)..... 45.90
Negative battery to starter switch cable (after #
9,005,625)..... 24.75

1931 STUDEBAKER Commander 70

Headlight & body..... cadmium 155.80
Headlight & body..... stainless 168.25
Cowl..... 69.25
Positive battery to ground strap..... 16.95
Negative battery to starter switch cable (before #
8,030,823)..... 31.35
Negative battery to starter switch cable (after #
8,030,829)..... 24.75

1931 STUDEBAKER President, Models 80 & 90

Note: All original conduit ferrule ends must be reused.

Main lighting kit:..... cadmium 152.80
Main lighting kit:..... stainless 183.20
Cowl..... 63.40
Positive battery to ground strap..... 16.95
Negative battery to starter switch cable (before #
8,030,823)..... 31.35
Negative battery to starter switch cable (after #
8,030,829)..... 24.75

1932 STUDEBAKER, Model 55

Main lighting w/ 1 or 2 taillights 144.50
Dash & engine..... 114.70
Dual horn harness (optional)..... 52.45
Headlight buckets/pr 21.90
Negative battery to starter switch cable 28.65
Positive battery to ground strap 18.65
Starter switch to starter motor cable 18.15
Engine to ground strap 16.55

1932 STUDEBAKER Dictator Eight, Model 62 & Commander Eight, Model 71

Starter switch to starter motor cable 15.90
Positive battery – ground strap..... 18.65

Negative battery – starter switch cable 28.65

1932 STUDEBAKER President Eight, Model 91

Positive battery – ground strap..... 18.65
Negative battery to starter switch cable
(after #8,030,823) 34.50
Negative battery to starter switch cable
(before #8,030,823)..... 34.20
Starter switch to starter motor cable..... 15.90

1932 early STUDEBAKER Rockne, Model 31

Negative battery to starter switch cable 34.90
Engine to ground strap 18.00
Starter switch to starter motor cable 19.80
Positive battery to ground strap..... 18.65

1932 late STUDEBAKER Rockne, Model 41

Negative battery to starter switch cable 28.65
Positive battery to ground strap 18.65
Engine to ground strap 17.75
Starter switch to starter motor cable..... 19.80

1933 STUDEBAKER Rockne, Model 31

Positive battery to ground strap..... 18.65
Engine to ground strap 17.75
Starter switch to starter motor cable 19.80

1933 STUDEBAKER Six, Model 56

Negative battery to starter switch cable 28.65
Positive battery to ground strap 18.65
Starter switch to starter motor cable 19.80
Engine to ground strap..... 17.75

1933 STUDEBAKER Commander Eight, Model 73 & President Eight, Model 82

Negative battery to starter switch cable..... 28.65
Positive battery to ground strap..... 18.65
Starter switch to starter motor cable (Model 92) .. 19.80
Starter switch to starter motor cable (Model 73) .. 19.80
Engine to ground strap 17.75

1934-35 STUDEBAKER Dictator, Model A, 1A & 2A

Headlight buckets/pr 28.20
Taillight buckets/pr..... 12.00
Spark plug wires..... 26.00
Engine to ground strap 17.75
Starter switch to starter cable (1934 only) 17.05
Positive battery to ground strap..... 18.50
Negative battery to starter switch cable w/ startix 34.90
Negative battery to starter switch cable w/o startix 31.35

1935 STUDEBAKER Commander 1B & President 1C

Engine, Headlight & body.....	205.95
Cowl w/ startix	116.40
Headlight buckets/pr	28.20

*Continued on next page.

1935 STUDEBAKER Commander 1B & President 1C – Continued

Taillight buckets/pr.....	12.00
Dual horns (President only)	45.40
Spark plug wires (President only)	33.00
Engine to ground strap	17.75
Starter switch to starter motor cable	18.15
Positive battery to ground strap.....	18.50
Negative battery to starter switch cable w/ startix	34.90

1936 STUDEBAKER Dictator, Models 3A & 4A

Battery to starter switch cable.....	38.50
Starter switch to starter motor cable	18.50
Engine to ground strap	17.75
Battery to ground strap.....	18.50

1936 STUDEBAKER Commander

Positive battery to ground strap	18.65
Negative battery to starter switch cable	38.50
Engine to ground strap.....	17.75

1936 STUDEBAKER President, Model 2C

Battery to starter switch cable w/ startix	38.50
Battery to starter switch cable w/o startix	34.90
Engine to ground strap	17.75
Battery to ground strap.....	18.50

1937 STUDEBAKER Dictator, Model 5A & 6A

Battery to starter switch cable	43.50
Positive battery to ground strap.....	18.50
Engine to ground strap	17.75

1937 STUDEBAKER President, Model 3C

Negative battery to starter switch cable	43.50
Positive battery to ground strap	18.50
Startix to starter cable.....	15.60
Engine to ground strap	17.75

1937 STUDEBAKER, Model J5

Battery to starter switch cable	43.50
Engine to ground strap	17.75
Battery to ground strap.....	18.50

1938 STUDEBAKER President, Model 4C

Battery to ground strap.....	18.50
Battery to starter switch cable.....	39.80

1938 STUDEBAKER Commander 7A & 8A and Coupe Express K5

Cowl, engine & headlight	267.90
Headlight buckets/pr.....cadmium.....	31.45
Headlight buckets/pr.....stainless	35.20
Instrument lights.....	25.75
Body & fuel tank wire.....	103.55
Taillight buckets/pr.....	24.00
Taillight cross-over.....	24.00
Horn relay to dual horns.....	23.95
Negative battery to starter switch cable	39.80
Positive battery to ground strap.....	18.50
Engine to ground strap.....	16.25
Startix to starter cable.....	19.80

1939 STUDEBAKER Coupe Express, Model L5

Engine to ground strap	16.25
Battery to ground strap.....	18.50
Battery to starter switch cable.....	32.40

1939-40 STUDEBAKER Champion, Model G & 2G, RHD

Starter switch to starter motor cable.....	16.00
Battery to starter switch cable.....	27.50

1939 STUDEBAKER Champion, Model G, (LHD)

Cowl, engine & headlight	258.30
License light & trunk light wire	5.40
Taillight buckets/pr.....	25.75
Engine to ground strap	16.25
Starter switch to starter cable	29.70
Battery to starter switch cable.....	27.50

1939 STUDEBAKER Commander, Model 9A

Battery to ground strap.....	18.50
Battery to starter switch cable (6 cyl).....	27.00

1939 STUDEBAKER President, Model 5C

Taillight buckets/pr.....	25.75
License light & trunk light wires.....	13.00
Engine to ground strap	17.50
Battery to ground strap.....	18.50
Battery to starter switch cable.....	24.00

1940 STUDEBAKER Champion, Model 2G

Headlight buckets/pr	46.20
Taillight buckets/pr.....	21.45
License light & trunk light wires	13.25
Overdrive harness	49.00
Windshield wiper harness.....	31.00
Clock & glove box.....	29.00
Horn wire – steering column	5.00

Body (2 dr)	92.40
Engine to ground strap	17.50
Starter switch to starter cable	29.70
Battery to starter switch cable	21.00

1940 STUDEBAKER Commander, Model 10A

Cowl, engine & headlight	282.40
Horn harness – 2 horns & horn relay	18.00
Headlight buckets/pr	46.20
Body harness (cpe)	102.85
Dome light wires (cpe)	18.20
Taillight buckets/pr	17.60
License light & trunk light	13.25
Windshield wiper harness	31.00
Overdrive harness	48.95
Clock & glove box	29.00
Steering column horn wire	5.00
Engine to ground strap	17.50
Battery to ground strap	18.50
Battery to starter switch cable	27.00

1940 STUDEBAKER President, Model 6C

Cowl, engine & headlight	280.00
Headlight buckets/pr	46.20
Body harness	103.20
Taillight buckets/pr	21.45
Windshield wiper harness	31.00
Clock & glove box	31.55
Overdrive harness	48.95
License light & trunk light wires	13.25
Horn wire – steering column	5.00
Misc. dash wires	9.70
Engine to ground strap	17.50
Battery to ground strap	15.40
Battery to starter switch cable	26.00

1941 STUDEBAKER Champion

Engine to ground strap	15.60
Battery to ground strap	18.50

1941 STUDEBAKER Commander

Engine to ground strap	15.60
Battery to ground strap	18.50

1941 STUDEBAKER President, Model 7C

Cowl, engine & headlight	282.00
Body harness	67.90
Overdrive control harness	56.95
Taillight harness	51.40
Positive battery to ground strap	18.50
Negative battery to starter cable	26.10

1941-42 STUDEBAKER MILITARY TRUCK, Model "US6"

Cowl, engine & headlight	155.75
--------------------------------	--------

Headlight buckets/pr	52.65
Headlight cross-tension harness	36.60
Headlight cross-over harness	36.00
Engine & generator harness	48.60
Misc. dash & horn wires	19.15
Body harness	165.85

1941-48 STUDEBAKER TRUCKS, Series M

Cowl, engine & headlight	228.95
Headlight buckets/pr	39.40
Body harness (113"wb)	81.15
Body harness (120"wb)	84.75
Body harness (128"wb)	86.25
Overdrive harness	76.00
Horn wires	14.95
Instrument light wires	30.25

1942 STUDEBAKER President

Battery to ground strap	18.50
-------------------------------	-------

1942 STUDEBAKER Commander

Engine to ground strap	15.60
Battery to ground strap	18.50

1942-26 STUDEBAKER Champion

Cowl, engine & headlight	295.20
Engine to ground strap	15.60
Battery to ground strap	18.50

1947-49 STUDEBAKER Champion, Commander & Land Cruiser

Cowl, engine & headlight	314.90
Headlight buckets/pr	36.00
Body & taillight w/ turns	142.65
Overdrive harness	63.55
Turn signal switch harness (optional)	16.30
Taillight buckets w/ turns (pr)	23.35
Park & turn buckets	18.30

1949-53 STUDEBAKER PICK-UP "R" Series

Cowl, engine & headlight	241.95
Cowl, engine & headlight w/o turns (1 ½ Ton) ...	245.00
Cowl, engine & headlight w/ turns (1 ½ Ton) ...	294.00
Headlight buckets/pr	39.75
Dash light wires (1 ½ Ton stake)	8.85
Turn signal harness (1 ½ Ton stake)	39.90
Body harness (1 ½ Ton, 12' stake body)	137.70
Body harness w/ turns (1 ½ Ton, 12' stake body)	165.80
Overdrive harness	64.90
Taillight buckets/ea.....cadmium	14.25
Taillight buckets/ea.....stainless	18.60

1950 STUDEBAKER Commander & Champion

Cowl, engine & headlight w/ turns..... 272.15
Body w/ turns 153.90
Overdrive harness 56.50
Headlight buckets w/ turns (pair) 45.90
Taillight buckets w/ turns (pair) 40.15

1951 STUDEBAKER Champion, Model 10G

Cowl, engine & headlight 238.10
Cowl, engine & headlight w/ turns..... 285.80
Headlight cross-over 28.30
Headlight cross-over w/ turns..... 35.50
Headlight & park light buckets/pr..... 52.75
Headlight, park light & turn buckets/pr 63.35
Overdrive harness 56.75
Anti-creep harness..... 55.75
Body harness 135.00
Body w/ turns 162.00
Horn harness 12.75
Horn button wire..... 5.75
Flasher & indicator light wires 21.75
Turn signal switch harness 44.15
Interior lighting harness 47.65
Trunk harness 20.50
Taillight buckets/pr 26.90

1951-52 STUDEBAKER Commander

Anti-creep harness..... 55.75
Overdrive harness..... 56.75

1953 STUDEBAKER Champion, Model 14G

Cowl, engine & headlight 239.95
Anti-creep control harness 53.20
Overdrive harness 57.25

1954 STUDEBAKER Champion, Model 15G

Anti-creep control harness 53.20
Overdrive harness 57.25

1955 STUDEBAKER

Positive ground strap..... 21.45

1956 STUDEBAKER Golden Hawk 56J

Cowl, engine & headlight w/ turns..... 381.25
Headlight buckets/pr 45.00
Misc. dash wires..... 11.85
Clock & clock light harness 21.90
Light & switch wires..... 22.25
Park & turn buckets/pr 21.50
Body & taillight harness 151.55
Positive battery – starter cable 21.45
Negative battery – ground cable..... 18.55
Spark plug wires..... 28.00

1956 STUDEBAKER Power Hawk 56B & Sky Hawk 56H

Cowl, engine & headlight 388.00
Headlight buckets/pr 45.00
Misc. dash wires..... 11.85
Clock & clock light harness 21.90
Light & switch wires..... 22.25
Park & turn buckets/pr 21.50
Body & taillight harness..... 151.55
Positive battery – starter cable 21.45
Negative battery – ground cable 18.55
Spark plug wires..... 28.00
Power window & related wires 86.55
Door switches & dome light harness..... 27.75

1957 STUDEBAKER Golden Hawk

Cowl, engine & headlight w/o overdrive (std)..... 359.00
Cowl, engine & headlight w/ overdrive (std) 390.25
Cowl, engine & headlight (automatic) 360.00
Headlight buckets/pr 41.20
Body w/ back-up lights..... 136.90
Back-up light switch harness..... 19.95
Park & turn buckets/pr 30.65
Taillight buckets/pr..... 44.50
Radio harness & cigarette lighter lights 35.30
Tachometer harness 27.50
Interior lights harness..... 27.95
Misc. wires..... 56.15
Back-up light buckets/pr..... 23.30
Trunk light harness..... 16.45

1963 STUDEBAKER Gran Turismo Hawk

Cowl, engine & headlight 527.00
Body 160.55
Headlight buckets/pr 45.35
Misc. under dash wires 42.85
Windshield washer harness 28.50
Park & turn buckets/pr 29.85
Taillight buckets/pr 34.50
License light bucket 10.40
Back-up light buckets/pr 24.00

STUTZ

1923-25 STUTZ Speedway 6-60, Model 690-695

Main cowl, engine, headlight & body – includes
Side light wires 208.25

1931-34 STUTZ DV 32 Super Bearcat

Cowl & dash harness 57.15
Main headlight & horn harness...stainless 175.95
Main headlight & horn harness...cadmium 161.15
Generator & coil – junction box...stainless 39.00
Generator & coil – junction box...cadmium 31.95

Main body harness 236.75

Horn relay to horn..... 6.50

TRACTOR

1947-48 EMPIRE TRACTOR, Model 90

Main harness 89.60
Starter to ammeter..... 29.05
Misc. wires 16.10

TUCKER

1948 TUCKER

Cowl, engine & main lighting 478.80
Headlight buckets/pr 65.50
Transmission remote control gear shift 143.90

1948 TUCKER with headlight's dimming rheostat & automatic transmission

Cowl, engine & headlight 447.95
Headlight buckets/pr 50.85
Misc. under dash wires 62.00
Generator to voltage regulator 34.70
Park & turn buckets/pr 18.00
Taillight buckets/pr 37.65
Taillight cross-over 62.00

WILLYS

1935-36 WILLYS

Cowl & main lighting 145.45
Headlight buckets/pr 51.95
Generator harness & coil 52.00
Taillight buckets/each 16.65
Starter switch to fuse harness..... 17.00

1946-50 WILLYS

Cowl, engine & headlight..... 259.00
Cowl, engine & headlight w/ options..... 310.80
Body 71.70
Body w/ options..... 89.60
Taillight cross-over..... 28.55
Taillight cross-over w/ options..... 32.50
Stop light switch & oil sender 23.80
Overdrive harness 76.85
Headlight buckets/pr..... 58.30
Park light buckets/pr..... 25.25
Park light buckets w/ options/pr..... 28.50
Left-hand taillight buckets 10.50
Left-hand taillight buckets w/ options 11.50
Instrument light wiring..... 15.75